



ВЕНЕТО









Шкаф











СТЛ.266.09



Assembly instructions




№	Размеры	Кол.	Пакет
1	352x2032x38	1	Пакет 1
2	352x2032x38	1	Пакет 1
3	350x150x38	2	Пакет 1
4	396x324x16	1	Пакет 2
5	396x324x16	4	Пакет 2
6	1986x468x3	1	Пакет 1
7	396x350x32	1	Пакет 2
8	392x154x16	1	Пакет 3
9	392x256x16	1	Пакет 3
10	392x416x16	2	Пакет 2
11	370x303x3	2	Пакет 2
12	300x160x16	1	Пакет 2
13	300x160x16	1	Пакет 2
14	356x147x16	1	Пакет 2
15	300x114x16	1	Пакет 2
16	300x114x16	1	Пакет 2
17	356x101x16	1	Пакет 2

0100 	0063  M4x25	0006 	0006  H = 0	0010  5x40	0083  L = 300MM	0009  7x50	0009 
8шт.	8шт.	4шт.	4шт.	4шт.	2шт.	4шт.	4шт.

0059  1.6x25	0032  4x13	0022 	0020 	0022 	0045  Ø8x30mm	0184  арт.РА375	0037  4x25	0054 	0094  5.1A
52шт.	20шт.	30шт.	30шт.	30шт.	28шт.	4шт.	2шт.	1шт.	1шт.





порядок
установки ящика
на направляющие.